



② - SUITABLE REINFORCEMENT REQUIRED FOR MOUNTING TRIM SCREWS.

① - TO ASSURE CORRECT ALIGNMENT OF TRIM, SCREW HOLES MUST BE LOCATED IN RELATION TO SPINDLE HOLE AFTER LOCK BODY IS INSTALLED IN DOOR (REF. TEMPLATE #7057)

SARGENT & COMPANY		NEW HAVEN, CONN. 06511	
TEMPLATE: 7800 & 8200 MORTISE LOCK ESCUTCHEON DESIGNS WT TRIM (SURFACE APPLIED)		RELEASE DATE	6 DEC 95
		TEMPLT NO.	7055 B