



③ INSTALLATION INSTRUCTIONS: ATTACH DOOR CLOSER TO WALL AND FOOT ASSEMBLY TO A DOOR. WITH DOOR CLOSED PUT ARM ON A SPINDLE (SEE DETAIL "A" FOR INDEXING). INSERT ROD INTO SWIVEL ARM AND ADJUST ACCORDING TO LENGTH INDICATED ABOVE. (TOTAL PRELOAD WILL BE 12°).

② RIGHT HAND DOOR SHOWN, LEFT HAND DOOR OPPOSITE.

① 12 GAUGE MIN. REINFORCEMENT REQUIRED FOR METAL DOORS AND FRAMES/WALLS.

SARGENT MANUFACTURING COMPANY

NEW HAVEN, CONN. 06511

DATA SHEET:
POCKET MOUNTING FOR 281-0
X 180° SERIES DOOR CLOSER

EFFECTIVE DATE
01 JAN 99
TEMPLET NO. A7335 B