

8877

8878

8800 Profile Series v.G1 Rim Exit Device**PARTS LIST****PAGE NO.****VG1.4****DATE:****REV.****B****August 2005**

ITEM	PART No.	DESCRIPTION	REQ'D
1	52-2839	Outside Escutcheon (Prox Only) Assembly (G1-PA, G1-TA)	1
	52-2474	Outside Escutcheon (Keypad Only) Assembly (LK)	
1	52-2838	Outside Escutcheon (Keypad/Prox) Assembly (G1-LU, G1-PK, G1-TU, G1-TP)	1
	52-2704	Key Pad and Proximity Assembly (G1-LU, G1-PK, G1-TU, G1-TP)	1
	52-2432	Keypad/Proximity Bezel Assembly w/ Harness (LK)	1
	52-2706	Proximity Only Assembly (G1-PA, G1-TA)	1
	68-1397	Outside Escutcheon Housing Only	1
	52-0176	Outside Escutcheon End Cap	1
2	52-2460	Inside Escutcheon Assembly with 100 User Controller (LK)	1
2	52-2833	Inside Escutcheon Assembly with 2000 User Controller (G1-LU)	1
2	52-2834	Inside Escutcheon Assembly with Prox/Key Pad Controller (G1-PA, G1-PK)	1
	52-2836	Inside Escutcheon Assembly (Keypad Only) with RF Technology Controller (G1-TU)	
	52-2835	Inside Escutcheon Assembly (Keypad/Prox or Prox Only) with RF Technology Controller (G1-TA, G1-TP)	
	68-1396	Inside Escutcheon Housing Only	1
	52-0175	Inside Escutcheon End Cap Only	1
	52-2441	100 User Controller Assembly (LK)	1
	52-2783	2000 User Controller Assembly (G1-LU)	1
	52-2784	2000 User Controller Assembly (G1-PA, G1-PK)	1
	52-2786	2000 User (Keypad/Prox or Prox Only) Controller Assembly w/ RF Technology (G1-TA, G1-TP)	
	52-2785	2000 User (Keypad Only) Controller Assembly w/ RF Technology (G1-TU)	
3	52-0170	Battery Cover	1
	52-2309	Battery Cover – RF Technology (G1-TU,G1-TP, G1-TA)	
4	01-1212	Security Screw	1
5	01-0297	Security Tool	1
6	52-0033	Fire Stop Plate	1
7	01-1500	Fire Stop Screws #8 x 1/2" Type "AB" Phillips Pan Head Self Tap	2
	01-0803	Battery Alkaline ("AA" Cell)	6
9	52-0253	Battery Keeper	1
	52-0344	Battery Keeper – RF Technology (G1-TU, G1-TP, G1-TA)	
10	52-2425	Screw Pack (Includes item numbers 5, 6, 7, 15)	1
11	Consult Factory	Motorized ET Lever Trim	1
12	Consult Factory	Motor and Harness Assembly	1
13	01-4451	ET Through-bolts	2
14	13-0074	Cylinder Retaining Screws	2
15	77-0685	Escutcheon Through-bolts	2
16	68-4261	Center Case Assembly LHRB & RHRB (Std.)	1
	68-4263	Center Case Assembly LHRB (12-) & RHRB (12-)	1
17	68-0406	Chassis Cover	1
18	97-0052	Chassis Cover Screws	4